
High speed response type with built-in output protection circuit

Features

- Reverse power polarity and overcurrent
- High speed response: Max. 1ms
- Light ON/Dark ON mode selectable by control wire
- Built-in the sensitivity adjustment VR (Except for through-beam type)







Specifications

N	IPN open collector output	BMS5M-TDT	BMS2M-MDT	BMS300-DDT	
Model P	NP open collector output	BMS5M-TDT-P	BMS2M-MDT-P	BMS300-DDT-P	
Sensing	type	Through-beam	Retroreflective	Diffuse reflective	
Sensing distance		5m	0.1 to 2m ^{*1}	300mm *2	
Sensing target		Opaque materials of Min. Ø10mm	Opaque materials of Min. Ø60mm	Translucent, Opaque materials	
Hysteresis		— Max. 20% at rated setting distance			
Response time		Max. 1ms			
Power supply		12-24VDC ±10%(Ripple P-P: Max. 10%)			
Current consumption		Max. 50mA	Max. 45mA		
Light source		Infrared LED(940nm)			
Sensitivity adjustment		— Adjustable VR			
Operation mode		Selectable Light ON or Dark ON by control wire			
Control output		NPN or PNP open collector output ◆Load voltage: Max. 30VDC ◆Load current: Max. 200mA ◆Residual voltage - NPN: Max. 1V, PNP: Max. 2.5V			
Protection circuit		Reverse power polarity, Output short-circuit(Overcurrent) protection circuit			
Indicator		Operation indicator: red LED, Power indicator: red LED(BMS5M-TDT1)			
Insulation resistance		Min. 20MΩ(at 500VDC megger)			
Noise resistance		±240V the square wave noise(pulse width: 1μs) by the noise simulator			
Dielectric strength		1000VAC 50/60Hz for 1minute			
Vibration		1.5mm amplitude at frequency of 10 to 55Hz(for 1 min.) in each of X, Y, Z directions for 2 hours			
Shock		500m/s²(approx. 50G) in each of X, Y, Z directions for 3 times			
Environ- ment	Ambient illumination	Sunlight: Max. 11,000 lx, Incandescent lamp: Max. 3,000 lx			
	Ambient temperature	-10 to 60°C, storage: -25 to 70°C			
	Ambient humidity	35 to 85%RH, storage: 35 to 85%RH			
Material		Case: ABS, Sensing part: Acryl(Through-beam: PC)			
Cable		Ø5mm, 4-wire, Length: 2m(Emitter of through-beam type: Ø5mm, 2-wire, Length: 2m) (AWG22, Core diameter: 0.08mm, Numner of cores: 60, Insulator out diameter: Ø1.25mm)			
Accesso	ries	_	Reflector(MS-2), VR adjustment driver	VR adjustment driver	
	Common	Mounting bracket, Bolts/nuts			
Approval		C€			
Unit weight		Approx. 180g	Approx. 110g	Approx. 100g	

^{※1:} It is mounting distance between sensor and reflector MS-2 and it is same when MS-5 is used. It is detectable under 0.1m.
When using reflective tapes, the reflection efficiency will vary by the size of the tape. Please refer to the "■Reflection efficiency by reflective tape model" table before using the tapes.

A-40 Autonics

 $[\]ensuremath{leph}$ 2: It is for Non-glossy white paper(100×100mm)


^{*}The temperature or humidity mentioned in Environment indicates a non freezing or condensation environment.

Amplifier Built-in type by Side Sensing

■ Feature data


Through-beam type

• BMS5M-TDT • BMS5M-TDT-P




◎ Retroreflective type

• BMS2M-MDT • BMS2M-MDT-P




Retroreflective type

• BMS2M-MDT • BMS2M-MDT-P



O Diffuse reflective type

● BMS300-DDT ● BMS300-DDT-P



A) Photo electric

(B) Fiber optic

(C) Door/Area

(D) Proximity sensor

(E) Pressure sensor

> (F) Rotary

encoder

Connector/ Socket

> (H) Temp. controller

(I) SSR/ Power

(J) Counter

(K)

(L) Panel

(M) Tacho/ Speed/ Pulse meter

(N) Display unit

(O) Sensor controller

(P) Switching mode power supply

(Q) Stepper motor& Driver&Controller

(R) Graphic/ Logic panel

(S) Field network device


(T) Software

(U) Other


Autonics A-41

Control output diagram

• NPN open collector output




• PNP open collector output



**Select Light ON / Dark ON by control wire. - Light ON: Connect control wire to 0V / Dark ON: Connect control wire to +V


Operation mode



**To prevent malfunction, this sensor maintains control output OFF for 0.5 sec. after supplying the power.

XIf the control output terminal is short-circuited or overcurrent condition exists, the control output turns OFF due to protection circuit.

Connections



XDark ON mode is on when control line is opened.

A-42 Autonics

Amplifier Built-in type by Side Sensing

Dimensions

(unit: mm)

Adjustment VR

(B) Fiber optic sensor

(C) Door/Area sensor

(D) Proximity sensor

(E) Pressure sensor

(I) SSR/

(M) Tacho/ Speed/ Pulse meter


(N) Display unit


(P) Switching mode power supply

(R) Graphic/ Logic panel

(S) Field network device

• Connect the bracket





2-Ø4.2


Reflector

16

Optical axis

Cable: Ø5, 2m

22 38.5




29

1


7.5 15

in emitter)





Reflective tape(sold separately)



	A	В
MST-50-10	50	50
MST-100-5	100	100
MST-200-2	200	200

Mounting and sensitivity adjustment


Install the sensor to the desired place and check the connections.

Supply the power to the sensor and adjust the optical axis and the sensitivity as follow;

Optical axis adjustment


Through-beam type

Set the photoelectric sensor in the middle of the operation range of the operation indicator adjusting the receiver or emitter right and left, up and down.




Retroreflective type

Mount the photoelectric sensor and the reflector or reflective tape face each other then fix them in the middle of operation range of the operation indicator adjusting the reflector(or reflective tape) right and left, up and down.



• Diffuse reflective type

Mount the photoelectric sensor and the target then fix them in the middle of operation range of the operation indicator adjusting the photoelectric sensor right and left, up and down.




O Sensitivity adjustment

Retroreflective type

Fix the adjustment VR at max.position and then check if the sensor operates normally to pass the target within sensing area of the sensor.

If the sensor does not work normally by noise or external shine, turn the adjustment VR slowly up to the position.

※If reflectance of target is higher than non-glossy
white paper, it might cause malfunction by reflection from
the target when the target is near to the photoelectric
sensor. Therefore enough space between the target
should be used and the photoelectric sensor or the
surface of the target should be mounted at angle of 30°
to 45° against optical axis.






※If the mounting place is too narrow, please use MS-5 instead of MS-2.

※Please use reflective tape(MST Series) for where a reflector is not installed.

• Diffuse reflective type

Set the target at a position to be detected by the beam, then turn the adjustment VR until position ⓐ where the operation indicator turns ON from min. position of the adjustment VR up to position ⓐ which the operation indicator turn ON from min.



Take the target out of the sensing area, then turn the adjustment VR until position where the indicator turns ON. If position b is not checked, the max.position is b. Set the adjustment VR in the middle of two switching position a, b. K Please be aware not to make the unstable operation of sensor by background and mounting side.

Reflective efficiency by reflective tape model

MST-50-10 (50×50mm)	160%
MST-100-5 (100×100mm)	230%
MST-200-2 (200×200mm)	360%

※Reflective efficiency may vary depending on usage environment and installation conditions.

The sensing distance and minimum sensing target size increase as the size of the tape increases.

Please check the reflection efficiency before using reflective tapes.

※For using reflective tape, installation distance should be min. 20mm.

A-44 Autonics